



**Audio System Upgrade Package
2011-UP Fiat 500 Subwoofer Kit
Installation Instructions**

CONTENTS:

**1ea. Subwoofer Assembly
1ea. Subwoofer Harness
1ea. Instructions
1ea. Wire Tie**

**Part # RU500
Part # FH500SUB
Part # RBI77KCK055
Part # RFZIP6**

TOOLS REQUIRED:

13mm Socket
Ratchet
Phillip's Screwdriver

Important!

Subwoofer system will only operate if optional amplifier upgrade (Kit # KCK054) has been previously installed.

1. Disconnect negative battery cable.
2. Remove the driver's side kick panel, and sill plate. Fig. 1
3. Remove the bottom of the back seat by removing the two bolts holding it in place. Fig. 2





**Audio System Upgrade Package
2011-UP Fiat 500 Subwoofer Kit
Installation Instructions**

4. Connect the two pin connector of the subwoofer harness to the two pin connector of the amplifier harness. Route the subwoofer harness from the amplifier location under the driver's seat to the driver's side trunk area.

Important!

If vehicle is equipped with optional Wi-Fi module, the module will need to be disconnected and removed to allow subwoofer to mount.

5. Plug in subwoofer and sit it in place on top of a sheet of paper or plastic bag to prevent the Velcro from engaging prematurely. Fig. 4
6. Use the factory screw at the top of the enclosure to secure the enclosure in place. While applying firm pressure to the front of the enclosure, slide the paper or bag out from underneath the enclosure. The Velcro should engage the carpet securing the bottom of the enclosure. Fig. 4



Fig. 3



Fig. 4

7. Re-install all previously removed parts in reverse order.
8. Insert fuse in the power harness.
9. Reconnect negative battery cable