



# INSTALLATION INSTRUCTIONS FLOOR MATS

**AUTHORIZED  
ACCESSORIES**

**ACCESSOIRES  
AUTORISEES**

**CONTENTS:** One set of floor mats

**TOOLS REQUIRED:** None

1. Locate retention post located in vehicle floor carpet directly below the front edge of driver's seat
2. Lay the front floor mats in the correct position inside the vehicle so the fastening eyelet on the driver's mat fits over the retention post.
3. the floor mats are custom designed to fit the floor pan

**CONTENU:** 1 set de tapis

**INSTRUMENTS REQUIS: 0**

1. Reperer la colonne de retention située directement devant le siège du conducteur sur le plancher.
2. Étendre le tapis sur le parque de façon à ne pas obstruer les pédales.  
Insérer le poste de tetention dans l'oeillet.
3. Ces tapis sont fabriqués sur mesure pour convenir a votre véhicule.

**Retention pin**  
Poste de retention.

