



INSTALLATION INSTRUCTIONS

BOLT ON EXHAUST FINISHER

Part Number MZ313948
MZ314572

GENUINE ACCESSORIES

APPLICATION



Mitsubishi Lancer Sportback 2010-



Mitsubishi Lancer, 2008-

TOOLS REQUIRED



4mm Allen Key



Safety Glasses

BILL OF MATERIALS

① x 1



② x 3



1 Preparation:

Park on a flat, dry surface
Turn off Ignition
Engage lowest gear or "PARK"
Engage Parking Brake

NOTE:

It is recommended that the tailpipe is washed prior to installation

2 Loosen the mounting screws from the exhaust finisher so that they do not protrude through to the inner surface of the tip.

CAUTION:

Beware of Sharp Edges

3 Holding the exhaust finishers in a horizontal position, slide the inside portion of the exhaust finisher over the muffler tail pipe.



4 Push and rotate the exhaust finisher into position on the tail pipe. Push the finisher back as far as possible on the tailpipe. Tighten the mounting screws until they make contact with the tailpipe.



PRODUCT CARE TIPS:

To clean polished stainless steel exhaust finishers, hand wash with mild detergent, dry and apply a good quality metal polish. NEVER USE AN ABRASIVE WASH PAD.

To maintain the polished appearance of your exhaust finishers, occasionally polish them using a Terry cloth and Mitsubishi detail polish or equivalent.

5 Torque the mounting screws to 19 inch/lbs. to ensure they are fully secure on the tailpipe.

INSTALLATION COMPLETE

