

Volvo Car Corporation Gothenburg, Sweden

Instruction No 31408213 Version 1.0 Part. No. 31373092

Parking assistance, front

© Volvo Car Corporation

Parking assistance, front- 31408213 - V1.0


Page 1 / 45



Volvo Car Corporation Gothenburg, Sweden


Materials	
Designation	Part number
Electrical tape	

VIDA MG-242205 A0000162





Volvo Car Corporation Gothenburg, Sweden





Volvo Car Corporation Gothenburg, Sweden

	36630-2 Parking assistance, front, R-design
	Information
1	Read through all of the instructions before starting installation.
	Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.
	Ensure that all tools stated in the instructions are available before starting installation.
	Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.
	In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.
	Further information
2	These installation instructions show installation on left hand drive cars.
	When installing on right-hand drive cars, perform the procedures on the opposite side and/or mirrored.
	Where the procedure differs, the right-hand version is also shown with text and image.
	Color symbols


© Volvo Car Corporation

Parking assistance, front- 31408213 - V1.0



Volvo Car Corporation Gothenburg, Sweden

3



IMG-363036

Note!

This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.

- 1. Used for focused component, the component with which you will do something.
- Used as extra colors when you need to show or differentiate additional parts.
- 3. Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
- 4. Used when the component is not fully removed from the vehicle but only hung to the side.
- 5. Used for standard tools and special tools.
- 6. Used as background color for vehicle components.

Removal

4

Set the ignition key to position 0.







IMG-340600


Installation instructions, accessories


Volvo Car Corporation Gothenburg, Sweden



Remove the panel.









Remove the weatherstrip.


© Volvo Car Corporation



Volvo Car Corporation Gothenburg, Sweden











Volvo Car Corporation Gothenburg, Sweden



IMG-344451





Fold the carpet to the side.




Volvo Car Corporation Gothenburg, Sweden

13


14

15

Locate the rubber grommet under the insulation and press it out.



Repeat on the other side.



Disconnect the connector, if applicable.

Repeat on the other side.




© Volvo Car Corporation


Parking assistance, front- 31408213 - V1.0




Volvo Car Corporation Gothenburg, Sweden



IMG-360124



Remove the panel.




Remove the weatherstrips.

IMG-307605 © Volvo Car Corporation



Volvo Car Corporation Gothenburg, Sweden


19



Detach the panel.

IMG-307606

20




Detach the panel.




Volvo Car Corporation Gothenburg, Sweden

21











Volvo Car Corporation Gothenburg, Sweden



Turn the wheel inwards.

IMG-341912

25



Remove the screws.

Vehicles with headlamp washers



IMG-341914


IMG-341915

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden



Fold the wing liner to one side.



Warning!

Be prepared to collect escaping fluid.

1.

Note!

Tape the hose high up on the washer fluid reservoir to previousher fluid from coming out.

2. Take a piece of washer hose. Tie a knot in it and place it on tl washer pump to prevent the washer fluid reservoir from emptying.


All vehicles



Volvo Car Corporation Gothenburg, Sweden


28

Turn the wheel inwards.




IMG-341916

29



Remove the screws.

30



IMG-341918


Fold the wing liner to one side.

© Volvo Car Corporation

Parking assistance, front- 31408213 - V1.0




Volvo Car Corporation Gothenburg, Sweden



Locate the connector.


IMG-378274

32



- 1. Depress the locking device.
- 2. Disconnect the connector.





RHD: The procedure is carried out on the opposite side.

© Volvo Car Corporation


Parking assistance, front- 31408213 - V1.0




IMG-307688

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden




RHD: The procedure is carried out on the opposite side.






Volvo Car Corporation Gothenburg, Sweden

Remove the clips.




37



Remove the clips.

Remove the screws.




© Volvo Car Corporation



Volvo Car Corporation Gothenburg, Sweden

39




Repeat on the other side.

The part is not to be reused.

IMG-378560


40



Remove the screws.

IMG-378108

41



Remove the clips.


IMG-378111 © Volvo Car Corporation

Parking assistance, front- 31408213 - V1.0



Volvo Car Corporation Gothenburg, Sweden

42



Repeat on the other side.

IMG-378561

43




Caution!

Place the Bumper Cover on a suitable surface.



Volvo Car Corporation Gothenburg, Sweden




The part is not to be reused.

Accessory installation

45

IMG-378579




Repeat on the other side.




Volvo Car Corporation Gothenburg, Sweden




Repeat on the other side.




IMG-378583








Volvo Car Corporation Gothenburg, Sweden




Repeat on the other side.


IMG-378591

50





IMG-378592



Connect the connectors.


© Volvo Car Corporation


Parking assistance, front- 31408213 - V1.0




Volvo Car Corporation Gothenburg, Sweden












IMG-378598





Volvo Car Corporation Gothenburg, Sweden






Attach the connector to the wiring harness.

The connector is not to be used.


Repeat on the other side.



© Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden



IMG-378603


Left hand drive vehicles




Use: , Electrical tape



Volvo Car Corporation Gothenburg, Sweden



IMG-378253



IMG-307882


Right-hand drive vehicles




IMG-373258


Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden



Use: , Electrical tape








Volvo Car Corporation Gothenburg, Sweden

All vehicles

64




Place the Bumper Cover in position for installation.

IMG-378609

Left hand drive vehicles

65



Connect the connectors.

Right-hand drive vehicles


© Volvo Car Corporation

Parking assistance, front- 31408213 - V1.0



Volvo Car Corporation Gothenburg, Sweden


66



Connect the connector.

IMG-378280

67




Connect the connector.

Vehicles with headlamp washers




Volvo Car Corporation Gothenburg, Sweden



Reinstall the removed parts in reverse order.

All vehicles



Reinstall the bumper.

IMG-378609

IMG-350323

Left hand drive vehicles



Volvo Car Corporation Gothenburg, Sweden




Caution!

Make sure to locate the wiring in such a way that any damage caused by heat or excessive wear is avoided.


Route the cable harness to the existing cable harness.

Reinstall the headlamp.





72



IMG-273586


Remove the nuts.

© Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden

73




.....

74



Pull the wiring through.

75



Install the cable.


IMG-273588 © Volvo Car Corporation



Volvo Car Corporation Gothenburg, Sweden


Right-hand drive vehicles

76



IMG-273585

77




IMG-307910




Volvo Car Corporation Gothenburg, Sweden

78

Install the cable.




79



Caution!


Make sure to locate the wiring in such a way that any damage caused by heat or excessive wear is avoided.





Volvo Car Corporation Gothenburg, Sweden


81



IMG-307914

All vehicles

82



Note!


Orientation view

Note!

On some markets the rubber grommet may be covered by the heat shield.




Volvo Car Corporation Gothenburg, Sweden




IMG-372722

84



IMG-373255

85




Pull the wiring through.




Volvo Car Corporation Gothenburg, Sweden

86




87



Insert the cable in to the passenger compartment, adjust the cable length out into the engine compartment and secure the rubber grommet.


88






Volvo Car Corporation Gothenburg, Sweden

Right-hand drive vehicles



IMG-308083


All vehicles





Volvo Car Corporation Gothenburg, Sweden






IMG-346331

Left hand drive vehicles

92

Connect the cable harness terminals in the connector as follows.



IMG-361341


Right-hand drive vehicles



Volvo Car Corporation Gothenburg, Sweden


93

Connect the cable harness terminals in the connector as follows.



IMG-361342


All vehicles





Volvo Car Corporation Gothenburg, Sweden

95



IMG-361377

96




Disconnect the connector, if applicable.

Attach the connector to the wiring harness.


Use: , Electrical tape

The connector is not to be used.




97

Disconnect the connectors.







Volvo Car Corporation Gothenburg, Sweden



The part is not to be reused.



Install component that comes with the accessory kit.




Connect the connectors.

© Volvo Car Corporation


Parking assistance, front- 31408213 - V1.0



Volvo Car Corporation Gothenburg, Sweden



Connect the prerouted cable.




Notel

Extra cable length must be secured using cable ties.



Volvo Car Corporation Gothenburg, Sweden

103



Download software (application) for the accessory's function according to the service information in VIDA.

Order and download software according to: 31266964

IMG-242268

104

Reinstall the removed parts in reverse order.