

Volvo Car Corporation Gothenburg, Sweden

Instruction No 31346068

Version

Part. No.


1.1


31350479, 31346065, 31407107


Trailer hitch, cable harness, and control module



Volvo Car Corporation Gothenburg, Sweden










Volvo Car Corporation Gothenburg, Sweden





Volvo Car Corporation Gothenburg, Sweden

INTRODUCTION

Read through all of the instructions before starting installation.


Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.

Ensure that all tools stated in the instructions are available before starting installation.

Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

1



IMG-363036


Color symbols

- Used for focused part, the part that you are to do something with.
- Used as extra colors when you need to show or highlight additional parts.
- 3. Used for fasteners to be removed/installed. May be screws, clips, connectors, etc.
- 4. Used when part is not removed completely from the vehicle but is only hung/suspended off to the side.
- 5. Used for standard tools and special tools.
- 6. Used as background color on vehicle parts.



Volvo Car Corporation Gothenburg, Sweden

2




Turn the ignition key to position **0**.


Note!

Wait at least three minutes before the connectors are unplugged or other electric equipment is removed.

IMG-245980



Removing





Volvo Car Corporation Gothenburg, Sweden

5




Remove the panel.

IMG-360187

6






Installing TRM

Use: Isopropanol, part number 1161721

Wipe dry.

IMG-362267





Use:Isopropanol, part number 1161721


Wipe dry.

© Volvo Car Corporation



Volvo Car Corporation Gothenburg, Sweden


8



Get the two Velcro straps from the kit and press them together, edge to edge.

IMG-356181


9





Volvo Car Corporation Gothenburg, Sweden


10



Remove the backing tape from one side of the Velcro straps.

IMG-241925


11



When installing Velcro tape the surface must maintain a temperature of at least +20 $^{\circ}$ C (68 $^{\circ}$ F).

IMG-356351

12




Remove the masking tape




Volvo Car Corporation Gothenburg, Sweden

13



Press the control module into place.


When installing Velcro tape the surface must maintain a temperature of at least +20 $^{\circ}$ C (68 $^{\circ}$ F).



Applies to cars model year from 2013-

Locate the connectors in the car's cable harness.

15




© Volvo Car Corporation

Plug in the located connectors.




Volvo Car Corporation Gothenburg, Sweden



Applies to cars model year up to and incl. -2012

Fold aside the insulation.






Locate the connectors.




Volvo Car Corporation Gothenburg, Sweden

18


Connect the extension cable harness to the located connectors.



IMG-360183



Route the extension cable harness along the existing cable harness.




© Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden

21



Plug in the connectors from the extension cable harness to the control module.






All vehicles

Press in the catches on the black lid on the fuse holder and remove it.






Install 40A fuse in position FA 11 in module RJB-A.

Reinstall the cover.

© Volvo Car Corporation



Volvo Car Corporation Gothenburg, Sweden



Installing trailer hitch cable harness



IMG-368513




Remove the rubber bushing in the floor and put it aside, it is not to be used anymore.



Volvo Car Corporation Gothenburg, Sweden

26




Note!


The rubber bushing should be installed so that the cable points to the left on the inside.

Insert the cable with the connector in the hole in the spare wheel well and install the rubber bushing.

Adapt the length of the cable from the socket (outlet) and to the rubber bushing so that the cable is not too slack under the car.



IMG-366117




Pull through the cable harness.

© Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden


29



Connect the connector.



31




© Volvo Car Corporation

Applies to vehicles with DVD-reader


Remove the screws.



Volvo Car Corporation Gothenburg, Sweden








Disconnect the connectors.



Volvo Car Corporation Gothenburg, Sweden

34




Applies to all vehicles

Fold aside the insulation.


IMG-366124

35



Applies to vehicles with chassis number up to and incl. - 175378

Locate the grounding points.



Note!


Connect to a free grounding point, in one of the three existing.

Install the cable and ground screw Tightening torque: M6, 10 Nm

© Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden



Applies to vehicles with chassis number up to and incl. from 175379-

Locate the grounding points.



Note!

10 Nm

Connect to a free grounding point, in one of the three existing.

Install the cable and ground screw Tightening torque: M6, 10 Nm

IMG-366131

39


Applies to all vehicles

Reinstall the removed parts in reverse order.



Volvo Car Corporation Gothenburg, Sweden

40




Download software (application) for the accessory's function according to the service information in VIDA.

See VIDA or the accessories catalog for software part number

IMG-242268

IMG-249951

41



Checking trailer socket

7-pin connection

- 1. Brake lights/Left turn signal
- 2. Ground
- 3. Spare (Brake lights, Electric brake)
- 4. Brake lights/Right turn signal
- 5. Charging
- 6. Running lights
- 7. Spare (Back-up light)

The cable for pin 3 for 7-pin connection is blue (BL). It is taped on the cable harness approx. 1 meter from the trailer socket.

4-pin connection

- 1. Brake lights/Right turn signal
- 2. Brake lights/Left turn signal
- Running lights
- 4. Ground