

Volvo Car Corporation Gothenburg, Sweden

 Instruction No
 Version
 Part. No.

 31408249
 1.0
 31373092


Parking assistance, front




Volvo Car Corporation Gothenburg, Sweden

Materials	
Designation	Part number
Electrical tape	


Equipment







Volvo Car Corporation Gothenburg, Sweden





1


2

Volvo Car Corporation Gothenburg, Sweden

36630-2 Parking assistance, front, R-design Information Read through all of the instructions before starting installation. Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation. Ensure that all tools stated in the instructions are available before starting installation. Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps. In the event of any problems with the instructions or the accessory, contact your local Volvo dealer. **Further information** These installation instructions show installation on left hand drive cars. When installing on right-hand drive cars, perform the procedures on the opposite side and/or mirrored. Where the procedure differs, the right-hand version is also shown with text and image. **Color symbols**



Volvo Car Corporation Gothenburg, Sweden



IMG-363036

4


Note!

This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.

- Used for focused component, the component with which you will do something.
- Used as extra colors when you need to show or differentiate additional parts.
- Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
- Used when the component is not fully removed from the vehicle but only hung to the side.
- Used for standard tools and special tools.
- Used as background color for vehicle components.


Removal

Set the ignition key to position 0.





Volvo Car Corporation Gothenburg, Sweden




6 WG-34926


Remove the weatherstrip.

Remove the panel.




Volvo Car Corporation Gothenburg, Sweden








Volvo Car Corporation Gothenburg, Sweden



IMG-344451




IMG-269484

Fold the carpet to the side.




Locate the rubber grommet under the insulation and press it out.



IMG-307603


13



Repeat on the other side.


Disconnect the connector, if applicable.


Repeat on the other side.






Volvo Car Corporation Gothenburg, Sweden





Remove the panel.




Remove the weatherstrips.




19

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden




IMG-307606



Detach the panel.

Detach the panel.







Remove the clips.

Remove the nuts.




Volvo Car Corporation Gothenburg, Sweden





IMG-341912



© Volvo Car Corporation

Remove the panel.

Turn the wheel inwards.

Remove the screws.




27

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden

Vehicles with headlamp washers

IMG-341914



Fold the wing liner to one side.

Warning!

Be prepared to collect escaping fluid.

Note!


Tape the hose high up on the washer fluid reservoir to prevent washer fluid from coming out.

Take a piece of washer hose. Tie a knot in it and place it on the washer pump to prevent the washer fluid reservoir from emptying.


All vehicles



Volvo Car Corporation Gothenburg, Sweden



IMG-341916




31 WG-341918 Turn the wheel inwards.

Remove the screws.

Fold the wing liner to one side.



Volvo Car Corporation Gothenburg, Sweden




Locate the connector.


IMG-378274

33

- Depress the locking device.
- Disconnect the connector.



IMG-378285





© Volvo Car Corporation

RHD: The procedure is carried out on the opposite side.



Volvo Car Corporation Gothenburg, Sweden






RHD: The procedure is carried out on the opposite side.




Volvo Car Corporation Gothenburg, Sweden

37


Remove the clips.





Remove the clips.

Remove the screws.






40

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden




Repeat on the other side.

The part is not to be reused.


Remove the screws.

Remove the clips.

IMG-378560




IMG-378108



IMG-378111 © Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden




Repeat on the other side.

IMG-378561




Caution!

Place the Bumper Cover on a suitable surface.



The part is not to be reused.

Accessory installation




Repeat on the other side.




47

Installation instructions, accessories


Volvo Car Corporation Gothenburg, Sweden



IMG-378583




49






Volvo Car Corporation Gothenburg, Sweden






IMG-378591



IMG-378592



© Volvo Car Corporation


RHD: The cable harness is positioned mirrored.


Repeat on the other side.

Connect the connectors.





Volvo Car Corporation Gothenburg, Sweden












Attach the connector to the wiring harness.


The connector is not to be used.

Repeat on the other side.








Volvo Car Corporation Gothenburg, Sweden




Left hand drive vehicles









Right-hand drive vehicles








IMG-341963



Volvo Car Corporation Gothenburg, Sweden


All vehicles

Place the Bumper Cover in position for installation.



IMG-378609

Left hand drive vehicles




Connect the connectors.


Right-hand drive vehicles



Volvo Car Corporation Gothenburg, Sweden



Connect the connector.




Connect the connector.

Vehicles with headlamp washers




Volvo Car Corporation Gothenburg, Sweden



Reinstall the removed parts in reverse order.

All vehicles




Reinstall the bumper.

IMG-378609

Left hand drive vehicles



Volvo Car Corporation Gothenburg, Sweden




Caution!


Make sure to locate the wiring in such a way that any damage caused by heat or excessive wear is avoided.

Route the cable harness to the existing cable harness.

Reinstall the headlamp.



IMG-273585





IMG-273586

Remove the nuts.




Volvo Car Corporation Gothenburg, Sweden





IMG-378516




Pull the wiring through.

Install the cable.



Volvo Car Corporation Gothenburg, Sweden

Right-hand drive vehicles



78 WG-307910


© Volvo Car Corporation




79

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden




Install the cable.



Caution!


Make sure to locate the wiring in such a way that any damage caused by heat or excessive wear is avoided.








Volvo Car Corporation Gothenburg, Sweden




All vehicles



Note! Orientation view


Note!

On some markets the rubber grommet may be covered by the heat shield.




IMG-372722

85



IMG-373255

86




IMG-377675


Pull the wiring through.



Volvo Car Corporation Gothenburg, Sweden




IMG-373254



Insert the cable in to the passenger compartment, adjust the cable length out into the engine compartment and secure the rubber grommet.


89







Volvo Car Corporation Gothenburg, Sweden

Right-hand drive vehicles




All vehicles





Left hand drive vehicles

Connect the cable harness terminals in the connector as follows.




IMG-361341

Right-hand drive vehicles




Volvo Car Corporation Gothenburg, Sweden

Connect the cable harness terminals in the connector as follows.




IMG-361342


All vehicles





Volvo Car Corporation Gothenburg, Sweden






Disconnect the connector, if applicable.

Attach the connector to the wiring harness.

Use: , Electrical tape


The connector is not to be used.




Disconnect the connectors.



Volvo Car Corporation Gothenburg, Sweden





IMG-378619 © Volvo Car Corporation The part is not to be reused.

Install component that comes with the accessory kit.


Connect the connectors.



103


Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden



Connect the prerouted cable.

Note!






104

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden



Download software (application) for the accessory's function according to the service information in VIDA.

Order and download software according to: 31266964

IMG-242268

105

Reinstall the removed parts in reverse order.