

Volvo Car Corporation Gothenburg, Sweden

Instruction No 31664127 Version

Part. No.

1.0


31664124, 31664123, 31664520, 31664521


Polestar Performance Intake and Exhaust kit



Volvo Car Corporation Gothenburg, Sweden

Materials	
Designation	Part number
Isopropanol	







Volvo Car Corporation Gothenburg, Sweden

1

Read through all of the instructions before starting installation.

Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.


Ensure that all tools stated in the instructions are available before starting installation.

Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

#### Color symbols

2



IMG-363036

#### Note!

This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.

- Used for focused component, the component with which you will do something.
- Used as extra colors when you need to show or differentiate additional parts.
- Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
- Used when the component is not fully removed from the vehicle but only hung to the side.
- Used for standard tools and special tools.
- Used as background color for vehicle components.


#### Removal



IMG-416095


#### Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden




Release the connector's catch.

Disconnect the connector.



Remove the screws.




Lift the marked component up

© Volvo Car Corporation

Polestar Performance Intake and Exhaust kit- 31664127 - V1.0



Volvo Car Corporation Gothenburg, Sweden




Lift the marked component up

Remove the marked part.

The part is not to be reused.

#### **Accessory installation**




Install component that comes with the accessory kit.




Volvo Car Corporation Gothenburg, Sweden

8


Reinstall the removed part.



IMG-416101



Tighten the bolts.



Connect the connector.




Volvo Car Corporation Gothenburg, Sweden

Clean the surface.

Use:, Isopropanol





Install component that comes with the accessory kit.


Removal



Volvo Car Corporation Gothenburg, Sweden


13

Locate relevant marking.




14

Use: Pipe cutter



15


Remove the marked part.





Volvo Car Corporation Gothenburg, Sweden


16



Remove the marked part.


IMG-421628

17



Remove the nuts.

18



Remove the marked part.


IMG-421630 © Volvo Car Corporation

Polestar Performance Intake and Exhaust kit- 31664127 - V1.0



Volvo Car Corporation Gothenburg, Sweden

19




Remove the marked part.

The part is not to be reused.

IMG-421617

20




Remove the marked part.



Volvo Car Corporation Gothenburg, Sweden

21



Remove the marked part.

IMG-421624

22



Remove the screws.

Applies to V60 models



Volvo Car Corporation Gothenburg, Sweden




Remove the marked part.

IMG-343213

#### All vehicles

24



Remove the screws.

On both sides.



Volvo Car Corporation Gothenburg, Sweden




Request the aid of a colleague for this procedure.

IMG-337279

#### Vehicles with parking assistance






Disconnect the connectors.

On both sides.



Volvo Car Corporation Gothenburg, Sweden




Remove the marked part.

On both sides.


IMG-347702

28



Disconnect the connector.

29




Loosen the clips.



Volvo Car Corporation Gothenburg, Sweden

#### All vehicles


30



Remove the screws.

On both sides.

31



Remove the clips.


On both sides.



Volvo Car Corporation Gothenburg, Sweden

32

Remove the marked part.



IMG-418706

33



Remove the marked part.

IMG-418702


**Accessory installation** 



Volvo Car Corporation Gothenburg, Sweden


34

Install component that comes with the accessory kit.



IMG-419136

#### Vehicles with towbar



Cut the component following the instructions in the graphic.


IMG-418752

#### Vehicles with parking assistance



Volvo Car Corporation Gothenburg, Sweden


36



Reinstall the removed part.

IMG-377956






Remove the clip.

The part is not to be reused.






Install component that comes with the accessory kit.



Volvo Car Corporation Gothenburg, Sweden


39



Install component that comes with the accessory kit.

Install the clips as illustrated.

IMG-421695




Install component that comes with the accessory kit.

Connect the connectors.

Position/route the cable harness as illustrated.

41



Place the Bumper Cover in position for installation.

Connect the connector.


IMG-337324 © Volvo Car Corporation

Polestar Performance Intake and Exhaust kit- 31664127 - V1.0



Volvo Car Corporation Gothenburg, Sweden

#### All vehicles



Note!

This step is easier with two people.

IMG-338572

#### Applies to V60 models



Reinstall the removed part.

IMG-347831

#### All vehicles



Volvo Car Corporation Gothenburg, Sweden

44




Install the screws.

On both sides.


IMG-337278

45



Install the screws.

46



Install component that comes with the accessory kit.

IIVIO-421010

© Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden

47

MG-421618

Install component that comes with the accessory kit.

48



Note!


Do not fully tighten the nuts yet.

Install component that comes with the accessory kit.

IMG-421619

49

Press the marked component.



IMG-421632


© Volvo Car Corporation

Polestar Performance Intake and Exhaust kit- 31664127 - V1.0



Volvo Car Corporation Gothenburg, Sweden

50




Tighten the nuts.

Tightening torque: M8 , 24 Nm

IMG-421615

51



Install component that comes with the accessory kit.




Volvo Car Corporation Gothenburg, Sweden

52

Press the marked component.



53




Tighten the nut.

Tightening torque: Exhaust clamp, 60 Nm

IMG-416182

54


Install component that comes with the accessory kit.






Volvo Car Corporation Gothenburg, Sweden

55



56




#### Note!

Do not fully tighten the bolts.

Install component that comes with the accessory kit.

57



#### Note!


Do not fully tighten the bolts.

Install component that comes with the accessory kit.

IMG-421633 © Volvo Car Corporation




Volvo Car Corporation Gothenburg, Sweden



Adjust to the specified value.

On both sides.

IMG-416819




Note!

Make sure that the component is centred.



Volvo Car Corporation Gothenburg, Sweden






Tightening torque: M8, 24 Nm








Adjust to the specified value.

On both sides.






#### Note

Make sure that the component is centred.



Volvo Car Corporation Gothenburg, Sweden

63



**Tightening torque:** End pipe, to Muffler (Allen screw), 5 Nm On both sides.