




# INSTALLATION INSTRUCTIONS

<b>Accessory</b> <b>ALL-SEASON FLOOR MATS</b> P/N 08P13-TX4-201A P/N 08P13-TX4-201B	<b>Application</b>  <b>2016 RDX</b>	<b>Publications No.</b> <b>VERSION 1</b>
		<b>Issue Date</b> <b>APRIL 2015</b>

## PARTS LIST


Driver's all-season floor mat




Passenger's all-season floor mat



Rear all-season floor mat



## Illustration of the All-Season Floor Mats in the Vehicle




## INSTALLATION


### NOTE:

- Remove the standard floor mats before installing the all-season floor mats.
- If you remove the all-season floor mat, make sure you re-anchor it when you put it back in your vehicle.
- If you replace the all-season floor mats, use factory all-season floor mats that are designed to be used with the anchors.
- If you use a non-factory mat in the driver's foot well, make sure it fits properly and that it can be used with the anchor.
- Do not put any additional mats on top of the anchored mat. An additional mat may slide forward and possibly interfere with the pedals.
- Identify each mat by the marks on the back of each mat: the mat marked "R" or "Passenger's side" goes on the right side of the vehicle; the mat marked "L" or "Driver's side" goes on the left side.

1. Install the rings in the driver's all-season floor mat over the anchors. Turn the knob on each anchor 90° to secure the driver's all-season floor mat.



2. Install the rings in the passenger's all-season floor mat over the anchors. Turn the knob on each anchor 90° to secure the passenger's all-season floor mat.



3. Position the rear all-season floor mat as shown.

