

Instruction Manual for Ashtray with Light

Thank you for purchasing NISSAN genuine products. Be sure to read this instruction manual before use, and use this product properly. After reading the manual, keep it in a safe and convenient place so that it can be referred to any time. The mark used in this manual and its meaning are as follows:

Ⓢ⚠️ **CAUTION** is especially important. Read carefully and follow the instructions.



⚠️ **CAUTION**

Instructions should be followed without fail for safety.
Failure to follow instructions may lead to injury or an accident.

Part number

F 8 8 0 0 - 8 9 9 2 A (ASHTRAY KIT)


Components



No.	Name	Quantity
①	Ashtray body	1
②	Steel plate	1
③	Instruction manual	1

Ashtray body,Lid:PF

(Fig.1)



To remove the battery box,remove this screw with a screwdriver. Be careful not to lose the removed screw.



How to use

- Use the ashtray as placing it in the center console cup holder.
- The white LED lights when the lid is opened, and goes out when the lid is closed.(When opening the lid, do it while holding the ashtray body with one hand.)
- If the bottom of the cup holder is flat, attach the steel plate to the bottom of the cup holder with double-sided tape for increased stability.
- When the LED lights dimly or it does not light, replace the battery.

How to replace the battery

- Remove the screw stud from the battery box (on the reverse side of the lid).
- Pull out the battery box in the direction of the arrow in Fig. 2.
- Pull out the battery (CR2032) in the direction of the arrow in Fig. 3.
- Install a new battery in reverse order of removal.
- Install the battery box in reverse order of removal.


(Fig.2)



⚠️ CAUTION

- Be sure to use the specified battery (coin-type lithium battery: CR2032).
- The battery has its own orientation. When replacing it, do not confuse the plus (+) and minus (-) sides of the battery.


Plus (+) side
Minus (-) side



- Do not tighten the screw fixing the battery box with excessive force. The lid or battery box may be damaged.

⚠️ CAUTION

- Use the ashtray when it is placed in the center console cup holder, etc. Do not use the ashtray while holding it in your hand. Doing so is dangerous resulting in burning your hand or causing a fire hazard.
- In a case where the ashtray to which a magnetic sheet is attached is used,never bring a magnetic card,etc.,close to the magnetic sheet.It may cause damage to the card.etc.
- Do not use the ashtray if there is a combustible item near the cup holder.
- If you open the lid while your finger is placed on the arrow portion shown in the drawing at your right,your finger may be pinched. Never open the lid while your finger is placed on the arrow portion.
- After using the ashtray, make sure that matches and cigarettes are extinguished, and be sure to close the lid. Also, do not put flammables, such as wastepaper, in the ashtray. This may cause a fire.
- When not using the ashtray, be sure to close the lid. Also, do not turn over the ashtray on a seat, etc. The contents may pop out.
- Do not apply excessive force to the lid when it is open. The lid, main body, battery terminals, etc., may be damaged or deformed.
- Keep out of water and keep hands off the conducting terminals in the battery box and at the hinge section. The LED may not light or may light erroneously. If the ashtray should be splashed with water only, use it after drying completely.
- Do not drop the ashtray on concrete or any other hard surface. It may be damaged or deformed.
- Do not rub the ashtray against a hard object because its surface is coated. The coating may be scratched.
- Do not install the ashtray with excessive force because there may be problems in installation or opening and closing of the lid depending on the shape of the cup holder.



* Be sure to hand this manual over to the customer.