



INSTALLATION INSTRUCTIONS

DESCRIPTION: COMPARTMENT SEPARATOR




TOOLS REQUIRED







FINAL ASSEMBLY



Meaning of Characters:






This product has been designed to allow for proper function of various vehicle safety components. The opening near the center of the separator is provided so that the shoulder strap belt for the rear center seat may be used without damaging the belt or compromising safety. In addition, spacing near the side windows on both sides of the separator are included in the design to allow for proper side curtain air bag clearances in the event of air bag deployment.




INSTRUCTIONS D'INSTALLATION

DESCRIPTION : SÉPARATEUR D'ESPACE



Signification des symboles :



Ce produit a été conçu pour permettre le fonctionnement adéquat de divers composants de sécurité du véhicule. L'ouverture ménagée près du centre du séparateur permet d'utiliser la ceinture épaulière de la place centrale arrière sans endommager la ceinture ni compromettre la sécurité. En outre, on a prévu de l'espace près des glaces latérales des deux côtés du séparateur pour laisser suffisamment de dégagement aux rideaux gonflables latéraux advenant leur déploiement.

