

Volvo Car Corporation Gothenburg, Sweden

 Instruction No
 Version
 Part. No.


 31390248
 1.0
 31390242, 31390245


Steering wheel



Volvo Car Corporation Gothenburg, Sweden

OLVC







Volvo Car Corporation Gothenburg, Sweden


	Information
1	Read through all of the instructions before starting installation.
	Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.
	Ensure that all tools stated in the instructions are available before starting installation.
	Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.
	In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.
	Further information
2	These installation instructions show installation on left hand drive cars.
	When installing on right-hand drive cars, perform the procedures on the opposite side and/or mirrored.
	Where the procedure differs, the right-hand version is also shown with text and image.
	Color symbols
3	
	Note! This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.
	 Used for focused component, the component with which you will do something.
	 Used as extra colors when you need to show or differentiate additional parts.
	 Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
	 Used when the component is not fully removed from the vehicle but only hung to the side.

IMG-363036

5. Used for standard tools and special tools.




Volvo Car Corporation Gothenburg, Sweden




IMG-345551

2





IMG-344722




Remove the panel.

Remove the panel.




Volvo Car Corporation Gothenburg, Sweden


9



¹⁰ mm



IMG-337683





© Volvo Car Corporation

Steering wheel- 31390248 - V1.0




Volvo Car Corporation Gothenburg, Sweden








Volvo Car Corporation Gothenburg, Sweden



IMG-345556






Repeat on the other side.

Repeat the steps when removing on opposite side.

Turn the steering wheel into neutral position.



Volvo Car Corporation Gothenburg, Sweden



Release the connector's catch.

Disconnect the connectors.

IMG-344731

19


18

Warning!

Place the airbag module with the front side facing up in a safe storage area during work.



Volvo Car Corporation Gothenburg, Sweden




Note!

This step requires considerable force.

Detach the panel.

IMG-345559




Note!

This step requires considerable force.

Remove the panel.

IMG-345560



Note!

This step requires considerable force.

Repeat on the other side.




Volvo Car Corporation Gothenburg, Sweden




Disconnect the connector.

Disconnect the connector.


Repeat on the other side.








Volvo Car Corporation Gothenburg, Sweden



IMG-373345



IMG-373339


Remove the screws.



28


Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden



Reinstall the screw.

Use hands only.




Remove the part carefully


30 IMG-344511 Remove the cable harness clips.



Volvo Car Corporation Gothenburg, Sweden




Accessory installation






Volvo Car Corporation Gothenburg, Sweden





IMG-373392



IMG-373394


Install the screw.

Remove the screw.


Install the screw.



Volvo Car Corporation Gothenburg, Sweden




Tightening torque: Steering wheel to steering column (center screw) , 48 Nm



Install the cable.

38




© Volvo Car Corporation

Repeat on the other side.




Volvo Car Corporation Gothenburg, Sweden



Repeat on the other side.


Installation

Repeat on the other side.






Volvo Car Corporation Gothenburg, Sweden



IMG-373389



© Volvo Car Corporation


Connect the connector.

Install the clip(s).


Install the cable.



Volvo Car Corporation Gothenburg, Sweden



IMG-344748



© Volvo Car Corporation

Install the panel.

Connect the connectors.

Caution!

Make sure that no part of the wiring harness is trapped.


Reinstall the removed parts in reverse order.



Volvo Car Corporation Gothenburg, Sweden

47

IMG-336901



Warning!

Reinstall the battery's negative cable.

When switching the ignition on for the first time after a battery disconnect and connect, make sure to stand outside the vehicle and only reach into the vehicle keeping clear of the air bag deployment areas.