

Accessory

ALL-SEASON FLOOR MATS

Application
2015 ACCORD
2 AND 4-DOOR

Publications No. **VERSION 1**

Issue Date AUG 2014

PARTS LIST

All-Season Floor Mats Kit (4-Door) P/N 08P13-T2A-100


Driver's all-season floor mat



Passenger's all-season floor mat



Rear all-season floor mats



All-Season Floor Mats Kit (2-Door) P/N 08P13-T3L-100

Driver's all-season floor mat



Passenger's all-season floor mat



Rear all-season floor mats





Illustration of the All-Season Floor Mats in the Vehicle




INSTALLATION


NOTE:

- An anchored mat is required for the driver's side of the vehicle; the anchor prevents the mat from sliding forward and possibly interfering with the pedals.
- If you remove the all-season floor mat, make sure you reanchor it when you put it back in your vehicle.
- If you replace the all-season floor mats, use factory allseason floor mats that are designed to be used with the anchor.
- If you use a non-factory mat in the driver's foot well, make sure it fits properly and that it can be used with the anchor.
- Do not put an additional mat on top of the anchored mat. It may slide forward and possibly interfere with the pedals.
- Identify each mat by the marks on the back of each mat: the mat marked "R" or "Passenger's side" goes on the right side of the vehicle; the mat marked "L" or "Driver's side" goes on the left side.

- 1. If equipped, remove the floor mats.
- Install the rings in the driver's all-season floor mat over the anchors. Push on the rings into the anchors to secure the retaining tabs, then turn the knob on each anchor 90° to secure the driver's all-season floor mat.




3. Place the passenger's all-season floor mat in the passenger's footwell.



4. Place the left and right rear all-season floor mats in front of the rear seats as shown.





2-Door: Install the ring in the right rear all-season floor mat over the anchor. Push on the ring into the anchor to secure the retaining tabs, then turn the knob on the anchor 90° to secure the right rear all-season floor mat.

