




GENUINE PARTS

INSTALLATION INSTRUCTIONS

DESCRIPTION:	Splash Guard Kit - Rear
APPLICATION:	JUKE
PART NUMBER:	999J2 6Z004


KIT CONTENTS:			
Item	Qty.	Part Description	Service Part Number
A	1	Splash Guard - Rear Left	999J2 6Z007
B	1	Splash Guard - Rear Right	999J2 6Z008
C	2	Push Pin (Long)	11296 AG000
D	2	Spring Clip (Short)	01241 00941
E	2	Spring Clip (Long)	12-41 0033U
F	4	Screw	01451 00891
G	1	Installation Instruction Replacement Template	N/A



A




B



C



D



E



F




G

TOOLS REQUIRED:	
<ul style="list-style-type: none"> • #2 Phillips head screwdriver • Clip remover • Drill • 6mm (1/4") Drill Bit 	<ul style="list-style-type: none"> • Clean, lint-free wiping cloth • Soap & water • Jack

PRE-INSTALLATION WARNINGS, CAUTIONS, CRITICAL STEPS, and NOTES:
<ul style="list-style-type: none"> • Dealer Installation Recommended. • These instructions are for left side of vehicle; same procedure applies to right side. • Jack up vehicle using instructions under "Changing Tire" section of owner's manual.


INSTALLATION PROCEDURE:




- 1) Jack up vehicle and remove rear wheel.

NOTE:

Jack up vehicle using instructions under "Changing Tire" section of owner's manual.




- 2) Remove and discard existing push pin.




- 3) Clean installation surface (shaded area) with soap & water.


INSTALLATION PROCEDURE:



- 4) Push splash guard to vehicle and align upper hole.
- 5) Confirm no gap and drill 6mm hole.




- 6) Slide spring clip (long) E up bumper flange and align with drilled hole.




- 7) Align splash guard to vehicle.
 - 8) Install push pin (long) C.
- NOTE:**
- Hold Splash Guard tight to vehicle while tightening screws to ensure no gap occurs between Fender and Splash Guard.
 - Do not over tighten screws. Reference Tighten Torque: 3.8~4.4 N-m {34~39 in-lb}
- 9) Install screw F.


INSTALLATION PROCEDURE:



- 10) Push splash guard lightly to vehicle and confirm no gaps.
- 11) Drill 6mm hole.



- 12) Install spring clip (short) D.



NOTE:

- Hold Splash Guard tight to vehicle while tightening screws to ensure no gap occurs between Fender and Splash Guard.
- Do not over tighten screws. Reference Tighten Torque: 3.8~4.4 N-m {34~39 in-lb}

- 13) Install screw F.

- 14) Reinstall rear wheel and remove jack.

FINAL INSPECTION

- Verify all clips are fully engaged and locked.
- Check all **torque** values. (Reference related steps and figures)
- Re-install all removed vehicle parts. Refer to vehicle service manual for more details.