



GENUINE PARTS


INSTALLATION INSTRUCTIONS

DESCRIPTION:	Rear Under-Seat Lockable Storage Bin
APPLICATION:	Titan
PART NUMBER:	999C2 W3002 (Crew Cab)

KIT CONTENTS:

Item	Qty.	Part Description	Service Part Number
A	1	Rear Under-Seat Lockable Storage Bin	N/A
B	8	M6 Bolt	14-66 0003U
C	2	Lock Cylinders	999S3 W4000
D	2	Grain Sticker	64892 W5000
E	1	Installation Instruction Replacement Template	N/A


E



A



B



C

D



STOP Important: Read Before Installation!

WARNING

For your personal convenience, please do not remove this warning. Before installation, please read the instructions carefully to avoid any damage to the vehicle. The installation instructions provide the necessary information for a safe installation.

CUSTOMER SAFETY & PROTECTION AND SAFETY INFORMATION: Customers can obtain the latest information on the latest safety recalls on their vehicles. Please visit us at www.nissanusa.com or call 1-800-NISSAN-USA. For more information, please visit us at www.nissanusa.com. For more information, please visit us at www.nissanusa.com. For more information, please visit us at www.nissanusa.com.

DEALER ASSISTANCE INFORMATION: Dealership technicians can obtain the latest information on the latest safety recalls on their vehicles. Please visit us at www.nissanusa.com or call 1-800-NISSAN-USA. For more information, please visit us at www.nissanusa.com.

TOOLS REQUIRED:

- 1/4 in. or 3/8 in. Drive Socket Wrench
- 6" Socket Extension
- 10mm Torque Socket
- Torque Wrench
- Scale
- Flashlight
- Utility Knife
- Fine Paint Marker (white)
- Safety Glasses





PRE-INSTALLATION WARNINGS, CAUTIONS, CRITICAL STEPS, and NOTES:

- Dealer Installation Recommended. Instructions may refer to Service Manual.

CAUTION


- Be careful of sharp edges and hanging components when under vehicle.
- Bolts must be tightened according to the specified torque values.
- Print templates to actual size and measure dimensions on the templates.
- Refer to owner's manual for operation and loading.

INSTALLATION PROCEDURE:




- 1) Lift seats into stowed position.
- 2) Place Lug Box onto floor with lock hole facing up and towards front of vehicle.
- 3) Push lug box rearward to contact carpet wall and center lug box in vehicle.
- 4) Open both lug box lids (driver side shown).
- 5) Use paint pen to mark carpet at 9 hole locations in bottom of lug box.
- 6) Close lids and remove lug box from vehicle.
- 7) Prepare templates A, B, C, and D by cutting out templates along dashed lines and circles in center of templates. See pages 6, 7, 8 and 9 for templates. Measure dimension on template. If dimensions are not to the scale, reprint template to actual size. Scaling must be set to "None" when printing.


INSTALLATION PROCEDURE: (continue)




- 8) On driver's side:
- a) Align template A with outermost paint marks as shown in Figure 5.
 - b) Using paint marker, mark carpet at 8 locations shown by black arrows on template.



- c) Align template B on driver side with paint marks as shown in Figure 6.
- d) Using paint marker, mark carpet shown by black arrows on template.




- 9) On passenger's side:
- a) Align template B on passenger side with paint marks as shown in figure 7.
 - b) Using paint marker, mark carpet shown by black arrows on template.




- c) Align template C on passenger side with paint marks as shown in figure 8.
- d) Using paint marker, mark carpet shown by black arrows on template.

INSTALLATION PROCEDURE: (continue)




- 10) Aligning template D on center carpet tunnel.
 - a) Align template hole to paint mark and make square with center floor tunnel as shown.
 - b) Using paint marker, mark carpet shown by black arrows on template.




- 11) Using utility knife, cut out carpet and upper layer of padding as shown by shaded area to expose the mounting brackets.

NOTE:

Do NOT remove lower layer of padding. Refer to Step 12 for further instruction.




- 12) Remove any lower layer of padding that interferes with mounting brackets.




- 13) Install and tighten bolt in order shown. Torque all bolts to 9 to 13 Nm. Put the grain sticker on visible hole in the middle of box.
- 14) Apply stickers over 2 open holes in box as shown.

INSTALLATION PROCEDURE: (continue)





- 15) Install rubber mats and dividers.



- 16) Close lid on driver's side. Install lock by inserting lock cylinder into lock assembly, lining up pie shaped poke yoke on cylinder with its corresponding hole in assembly. Push cylinder in until a click is heard.


NOTE:

Do not install the lock cylinder with the key inserted into it.




Cut Along Dashed Lines and Center Holes

SCALE:
1" (25.4mm)




Set scaling to "None" when printing




**Cut Along
Dashed Lines
and Center
Holes**


SCALE:
1" (25.4mm)




Set scaling to "None"
when printing



SCALE:
1" (25.4mm)




Set scaling to "None" when printing



Cut Along Dashed Lines and Center Holes

SCALE:
1" (25.4mm)



Set scaling to "None" when printing